

DIALINE BUYERS GUIDE

13904 - X - X - X

number from **SECTION 1**

number from **SECTION 2**

number from **SECTION 3**

This is a step by step guide to assist in assembly of all things required to properly attach a Dialine cutting head to any waterjet. This page configures the cutting head, the reverse side covers other items required to complete the package.

Each "x" in the part number above corresponds to a section below. Choose an option from each section to complete your customized Dialine part number.



Choose the ABRASIVE BODY

Option 1 is standard cutting head body for use with .300 OD nozzles. Option 2 is also a standard cutting head body and utilizes .281 OD nozzles. Option 3 features two abrasive inlets, primarily used for piercing brittle materials, it also uses .281 OD Nozzles.



Abrasive Body for .300 nozzles



Abrasive Body for .281 nozzles



Dual Inlet Body for .281 nozzles

ABRASIVE INLET

Option 1 is for a standard 3/8" abrasive feed line. Option 2 is for a smaller 3/16" abrasive feed line, which is typically used on Omax style equipment.



Inlet for 3/8" tubing



Inlet for 3/16" tubing

Choose the NOZZLE NUT

Option 1 is a standard nozzle nut. Option 2 & 3 offer a protective nozzle nut, which feature a replaceable rubber splash guard and a carbide braised nut. Option 2 is for use with 3" long nozzles, while option 3 is for 4" long nozzles.



Standard Nut



3" Nozzle Nut with Nozzle Guard



4" Nozzle Nut with Nozzle Guard



COMPLETE THE PACKAGE

The products below are required to complete the DiaLine Package. Choose the products that best work with your machine.

CONNECTION

Select from an extensive line of adapters to ensure a seamless fit to your machine.

MT Style

Standard

Flow Style



Standard Tube



Swivel Adapter

OMAX Style



Integrated



Non-Integrated





Swivel Adapter

JE Style



Short Swivel



Medium Swivel



Long Swivel

Options below are for pure water cutting applications.



Water only nozzle retainer





DiaLine water only conversion kit 1

ORIFICE Select from diamond or ruby orifices in a wide range of size orifices in a wide range of sizes



Diamond Orifice Available in .008-.018



Ruby Orifice Available in .004-.020



13904-1-1-1 with 13841 Adapter

.300 DiaLine with 3/8" Inlet, Standard nut and JE Medium Swivel

INVESTMENT

In order to maximize the life of your DiaLine Diamond AccuStream recommends the use of our Thimble style filter. A 600 hour warranty on the Diamond orifice is offered to those customers using the thimble filter. The Thimble filter is a small stainless filter with very small holes drilled in a unique pattern to capture any foreign debris which might damage the diamond.



3/8"F to 3/8" M **HP Kit 13174**



1/4" F to 3/8" M **HP Kit 13553**



1/4" F to 1/4" M **HP Kit 14279**

